

# aspire® Tigon Kit User Manual

Read this information leaflet fully before you start using this product as it contains important information. The notes below relate to when the device is filled with e-liquid that contains nicotine.

This product is intended for adult smokers. This product is not recommended for non-smokers, young people under the age of 18 years, pregnant or breast feeding women and those experiencing general ill health.



Keep out of reach of children and minors!

**This product contains nicotine which is a highly addictive substance.**

The above warning only applies when this device has been filled with nicotine containing e-liquid

## Kit Contents:

- 1\* Tigon Kit
- 1\* Glass tube
- 2\* Ni80 Coils (1\*1.2Ω & 1\*0.4Ω preinstalled)
- 1\* Screw adjustment tool
- 10\* O-rings
- 1\* Extra drip tip
- 1\* USB cable
- 1\* User manual
- 1\* Warranty card

## Tigon Tank Features

- Super easy top fill
- Child resistant
- 2ml capacity
- Bottom adjustable airflow
- E-liquid sealing mechanism
- Coil resistance: 1.2Ω(10-12W) & 0.4Ω(23-28W)
- Great vapor and flavor production
- Super efficient wicking
- Suitable for both MTL hits and restricted lung hits
- Diameter: 22.3mm
- Length (including drip tip): 61mm

## Tank Filling

1. Pull the top cap up, place your thumb on the top cap right on the drop symbol.
2. Push the top cap away until the filling hole is revealed.
3. Add your preferred e-liquid into the tank through the filling hole.
4. Slide the top cap back into place.
5. Press the top cap down firmly to seal.



- When using a new coil, let the tank stand for 5 minutes after filling so the cotton can be saturated with e-liquid before use.
- Do not let the tank become completely empty. Refill the tank to avoid dry burning or damage to the coil.

1

## Coil Installation

1. Unscrew to remove the base hardware.
2. Pull to remove the used coil.
3. Put a new coil into the chamber.
4. Screw the base hardware back onto the tank.

*NB: Coil can be replaced even when the tank is full.*



## Glass Tube Replacement

1. Unscrew to remove the base hardware.
2. Pull to remove the coil and use the screw adjustment tool to loosen and remove the small screw from inside the metal chamber.
3. Unscrew to detach the top hardware from the tank.
4. Replace the used glass tube with a new glass tube and replace the top hardware.
5. Use the tool to lock the screw back into the chamber tightly and insert the coil back into the tank.
6. Screw the base hardware back into place.



2

## Mod Specifications

- Output wattage: Bypass
- Output voltage: 3.3-4.2V
- Continuous firing time: 10 seconds
- Battery Type: Built-in
- Battery capacity: 1800mAh
- Diameter: 22mm
- Length: 79mm

## Instructions

- Press the fire button 5 times within 2 seconds to either lock or unlock the device. The LED light will flash pink 3 times at the same time.
- When the device is on press the fire button, the LED light will indicate your device's current charge. When its current charge capacity is above 3.8 volts the indicator light will be pink. When the charge is between 3.8 and 3.5 volts the light will be blue. When the charge drops below 3.5 volts the light will then become red to remind you that it is time to charge your device.

## Protection Features

- Automatic Cutoff: The preset continuous fire time is 10 seconds, after 10 seconds of continuous firing, the device will stop firing and the LED light will flash 10 times, it will fire again when the button is pressed.
- Short Circuit Protection: When the device detects a short, it will stop firing, and the LED light will flash pink 3 times.
- Low Voltage Protection: When the battery level drops below 3.2V, the device will not function and the LED light will flash red 15 times.
- Overcharge Protection: When the device is fully charged, it will stop charging to prevent overcharging of your battery.
- Over heat protection: When the temperature of the control board is above 75 C/167 F, the LED light will remain on pink for 3 seconds to indicate an overheat and the device will cut off.

3

## Charging Instructions

- Charge via the Micro USB port. Maximum charge current can reach up to 2A.
- When the USB cable is attached or detached the device indicator light will flash pink 3 times. While charging the LED will indicate the device's current charge status: 3.5 volts or less= red light; 3.5 to 3.8 volts= blue light; 3.8 volts and above= pink light. When the device is fully charged the LED will flash pink 20 times then remain off.

## IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS

Before using nicotine containing e-liquids the user should read the following information carefully.

## NICOTINE CONTAINING E-LIQUIDS:

Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

## WARNINGS AND PRECAUTIONS

- Nicotine containing e-liquids are not recommended for:
  - Non-smokers
  - Young people under the age of 18 years;
  - Pregnant or breast feeding women; as nicotine is known to cross the placenta and to be excreted in breast milk;
  - Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma;
  - Those who have an overactive thyroid gland or have a pheochromocytoma (a tumour of the adrenal gland that can affect high blood pressure);
  - Those who have diabetes, as nicotine may affect your blood sugar levels.
- Those taking the following medication;
  - Theophylline (to treat breathing problems)
  - Ropinirole (to treat restless leg syndrome)
  - Clozapine (to treat schizophrenia)

4

## POSSIBLE SIDE EFFECTS

If you inhale too much nicotine or use the product too much you may experience one or more of the following effects:

- Feeling faint;
  - Nausea (feeling sick)
  - Headache
  - Coughing
  - Irritation of the mouth or throat
  - Dizziness
  - Stomach discomfort
  - Hiccups
  - Nasal congestion
  - Vomiting (being sick)
  - Heart palpitations
  - Abnormal heart rate
- If you experience any of these side effects; including any possible side effects not listed in this leaflet, discontinue using the product, if the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.

## Safety note:

To avoid misfiring always ensure you either lock or switch off your device when it is not in use. Especially when carrying your device in your pocket, bag or purse.



\*Diameter of the pod refill hole.

To learn more about our products and how to use, please visit: [www.aspirecig.com](http://www.aspirecig.com)

Shenzhen Eigate Technology Co., Ltd.

Building 3, Xinhongtai Industrial Park, 14 Jian'an Rd, Tangwei, Fuyong Town, Bao'an District, Shenzhen, China  
Tel: +86-755-81499783 Email: [service@aspirecig.com](mailto:service@aspirecig.com)

Manufactured By Eigate MADE IN CHINA



5